

# RS232 Option Module (12980)

## INSTALL SHEET

This document covers the mounting and wiring of the RS232 option module (12980) for a JACE-8000 controller (12977).

**Model / Description: NPB-8000-232 (12980):** Single port, electrically isolated RS232 adapter with DB9 male connector. An onboard UART supports baud rates up to 115200. LEDs verify power from the controller and indicate RS232 message traffic.

**Module Combinations:** A maximum of four RS232 modules are supported. The controller supports a maximum total of four option modules across all option types. If two Dual RS485 modules are used, only one additional non-RS485 module may be added for a maximum total of three modules.

**COM Port Assignments:** The controller has two *onboard* RS485 ports that always operate as COM1 and COM2. Installed serial option modules continue COM port numbering based on proximity to the controller, where the option module closest to the controller base operates as the next available serial COM port(s). For example, if attached directly to the controller, this RS232 option module operates as COM3. For related details, see “[COM port usage](#),” page 2.

Related topics such as the mounting and wiring of the controller or other option modules, installation of Niagara 4 software, and usage of the various RS232-based drivers are in other documents. See “[Related documentation](#),” page 3.

### Included in this package


Included in this package you should find the following items:

- One RS232 option module (12980)
- This *RS232 Option Module (12980) Install Sheet*

### Material and tools required

Suitable tools and fasteners for mounting the unit, attaching it to an already mounted JACE-8000 controller. DIN-rail mounting of the controller and all its option modules is recommended.

Figure 1 RS232 Option module.



1 RS232 port with standard DB9 male (plug) connector. Operates as COMn (*next available*). For example, COM3

## Precautions

The following are warnings relating to the installation of the controller option module.

### General precautions



**Caution** Remove all power to controller before attaching (plug in) or detaching (unplug) any option module, to prevent possible equipment damage.



**Caution** Removal of the cover is not required. No configurable or user-serviceable items (such as jumpers) are inside the option module.

### Static discharge precautions

Static charges produce voltages high enough to damage electronic components. The microprocessors and associated circuitry within the devices are sensitive to static discharge.



**Caution**

- Work in a static-free area.
- Discharge any static electricity you may have accumulated. Discharge static electricity by touching a known, securely grounded object.



## Mounting

Mounting the controller and all option modules on a 35mm wide DIN rail is recommended. Mounting on a DIN rail ensures accurate alignment of connectors between all modules. Tabs on the controller or module can be used for panel mounting as an alternate to DIN rail mounting.




**Caution** Remove all power to controller before installing or removing option modules. See “[Precautions](#),” page 1.


### Mounting on DIN rail

**Prerequisite:** JACE-8000 controller is securely mounted on a 35mm DIN rail, with adequate room left to mount the module.

1. Pull the option module's locking clip down.




2. Tilt the module to hook over the DIN rail.
3. Push down and in on the unit, fastening to the rail.
4. Slide the module firmly into the controller's connector (or existing option module) to seat.



Repeat for other modules as needed (4 maximum).

5. Push up the locking clip on all modules.



6. Carefully secure both ends of the final assembly with DIN rail end-clips provided by the DIN rail vendor.

**NOTE:** To remove a unit from the DIN rail, pull down its locking clip. Slide the unit away from other devices, then swing the bottom out and lift away from the rail.

### COM port usage


The RS232 option adds one COM port on the installed JACE-8000 controller. The controller has two *integral* RS485 ports. In a Niagara 4 station running on the controller, these two ports always operate as COM1 and COM2.

Installed serial option modules (RS232 or RS485) continue COM port numbering based on proximity to the controller, where the option module closest to the controller base operates as the next available serial COM port(s).

For example, if attached directly to the controller, this RS232 option module operates as COM3. If another RS232 option module is chained to it, it operates as COM4.

[Figure 2](#) shows a few combinations with port assignments.

**Figure 2** COM port numbering examples.



## Wiring


### Earth ground wiring

Other than the controller ground, no ground is required on the module.

### RS232 port pinouts

The RS232 option module has DB9 male (plug) connector, typical for a DTE device. [Table 1](#) provides pinouts.

**Table 1** RS232 option module port pinouts.


Pinout Reference	Signal	DB-9 Plug Pin
<b>DB9M (male or plug)</b> 	DCD	1
	RXD	2
	TXD	3
	DTR	4
	GND	5
	DSR	6
	RTS	7
	CTS	8
	not used	9

Standard DB9 serial cables may be used—for example, a “null modem” cable to communicate to another DTE device. Shielded type cables are recommended, with a typical maximum length of 50 feet (15.2m).

### LEDs

Three LEDs are on the front of the RS232 option module.

**Figure 3** LEDs on RS232 option module.



The LED pair TX and RX operate as follows:

- TX (yellow) — Transmit, flashes when the controller is sending data to a device on the RS232 port.
- RX (green) — Receive, flashes when the controller is receiving data from a device on the RS232 port

LEDs are also visible when the front access door is opened.

### Related documentation

For more information on installing, configuring, and using the JACE-8000 controller with RS232 option module, refer to the following documents:

- *JACE-8000 Controller (12977) Mounting and Wiring Guide*
- *JACE-8000 Controller (12977) Quick Start Install Sheet*
- *JACE-8000 Niagara 4 Install and Startup Guide*
- *Niagara 4 Drivers Guide*

Information and/or specifications published here are current as of the date of publication of this document. Tridium, Inc. reserves the right to change or modify specifications without prior notice. The latest product specifications can be found by contacting our corporate headquarters, Richmond, Virginia. Products or features contained herein are covered by one or more U.S. or foreign patents. This document may be copied by parties who are authorized to distribute Tridium products in connection with distribution of those products, subject to the contracts that authorize such distribution. It may not otherwise, in whole or in part, be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form without prior written consent from Tridium, Inc. Complete confidentiality, trademark, copyright and patent notifications can be found at: <http://www.tridium.com/galleries/SignUp/Confidentiality.pdf>. © 2015 Tridium, Inc.